

Feature Codes

ACTION	DESCRIPTION	DIAL
Enable Call Forward	Turn call forwarding on	*72
Disable Call Forward	Turn call forwarding off	*73
Toggle Call Forward	Flip call forwarding on or off	*74
Update Call Forward	Change the number forwarding goes to	*56
Park and Retrieve	Park and Retrieve a call. IE. Blind Transfer to *31 to Park. Call *31 to Retrieve.	*3
Valet	Valet park a call. System will announce the parking slot number.	*4
Retrieve	Retrieve a Valet-parked call. *51 followed by slot number. IE. *5100	*5
Check Voicemail	Call *97 to check voicemail box.	*97
Direct to Voicemail	Send call directly to voicemail. IE. Blind Transfer to **101	**
Intercom	Place an intercom call. *0 followed by the extension number. IE. *0101	*0
Privacy	Make an anonymous call. *67 followed by the number. IE. *678005551212	*67
Direct Pickup	Pick up call ringing another user. *8 followed by the user extension. IE *8100	*8

Not All Feature Codes May Be Active